

FREEMAN CAGE NET™
FREEMAN BY DESIGN CORPORATION
ANIMAL HANDLING PRODUCTS FOR PROFESSIONALS.
www.FreemanByDesign.Com

Please fully read this page of directions and warnings before proceeding.

Good for animals up to 12Kgs (25lbs)

TO OPEN the net for use, unravel the netting from the frame. Put one hand on the black plastic grip and the other hand on the black tube handle on the end of the net, and push it toward the grip.

TO SECURE the animal inside the net, pull the black plastic handle back toward the end of the net and roll the net at least one full turn. This will seal off the opening. Rolling the net also takes the stress off the hoop wire.

TO CARRY: an animal in the net, by holding the pole horizontally, this helps keep your hands clear of the netted animal and is the least stress on the net mechanisms.

NEW! A FULL LENGTH LOCKING ZIPPER ACROSS THE BOTTOM OF THE NET BAG. THIS FEATURE MAKES FOR EVEN EASIER RELEASES AND EASIER ACCESS TO THE ANIMAL FOR TREATMENT AND INSPECTION.

WARNING! Please read!

Keep clear of overhead wires

Safe use of this tool includes but is not limited to:

Training

Practice

Knowledge and being familiar with the animals you are attempting to handle.

Do not put yourself at risk

All animals can be unpredictable.

CARE:

Always store the net in a closed position away from direct sunlight.

You can spray down the net all you like as it is made of no rust aluminum and stainless steel. The netting is 100% nylon and will not rot.

Do not use bleach, it will damage the netting and mechanisms. Use fabric softener in a dip bucket if the netting stiffens from cleaners. You may also find it helpful to periodically lube the track (inner tube area) where the round piece of plastic travels with general-purpose grease to reduce the sticking that may happen after cleaning & spraying down the net many times.

Be gentle.

WARNING! Please read!

Use at your own risk.

The use of this device is entirely at the discretion of the user. The user accepts complete responsibility for the use of this device. The user must become fully aware of its operation before using. Freeman By Design Corporation assumes no responsibility or liability for any damage(s) or accident(s) resulting from the use of its products whatsoever.

TAKE CARE

PRODUCT FEEDBACK- peter@freemanbydesign.com

Thank you for using Freeman products.

Direct all other inquiries to:

ANIMAL CARE EQUIPMENT & SERVICES

555 ALTER STREET UNIT 19A

BROOMFIELD, COLORADO

80020 USA TEL. 303-296-9287

1-800-338-ACES

info@animal-care.com

www.animal-care.com